

## **Technical data sheet**

CH24-L100

Linear actuator for adjusting dampers and slide valves in technical building installations

- Actuating force 125 N
- Nominal voltage AC/DC 24 V
- Control Open/close, 3-point
- Length of Stroke Max. 100 mm, adjustable in
- 20 mm increments



**Technical data** 

Electrical data	Nominal voltage	AC/DC 24 V
	Nominal voltage frequency	50/60 Hz
	Nominal voltage range	AC 19.228.8 V / DC 19.228.8 V
	Power consumption in operation	0.5 W
	Power consumption in rest position	0.2 W
	Power consumption for wire sizing	1 VA
	Connection supply / control	Cable 1 m, 3 x 0.75 mm <sup>2</sup>
	Parallel operation	Yes (note the performance data)
Functional data	Actuating force motor	125 N
	Direction of motion motor	by electrical installation
	Manual override	with magnet
	Stroke	100 mm
	Length of Stroke	Max. 100 mm, adjustable in 20 mm increments
	Stroke limitation	can be limited on both sides with mechanical end stops
	Running time motor	380 s / 100 mm
	Sound power level, motor	35 dB(A)
Safety data	Protection class IEC/EN	III, Safety Extra-Low Voltage (SELV)
	Power source UL	Class 2 Supply
	Degree of protection IEC/EN	IP54
	Degree of protection NEMA/UL	NEMA 2
	Enclosure	UL Enclosure Type 2
	EMC	CE according to 2014/30/EU
	Certification IEC/EN	IEC/EN 60730-1 and IEC/EN 60730-2-14
	UL Approval	cULus according to UL60730-1A, UL60730-2-14 and CAN/CSA E60730-1 The UL marking on the actuator depends on the production site, the device is UL-compliant in any case
	Type of action	Туре 1
	Rated impulse voltage supply / control	0.8 kV
	Pollution degree	3
	Ambient humidity	Max. 95% RH, non-condensing
	Ambient temperature	-3050°C [-22122°F]
	Storage temperature	-4080°C [-40176°F]
	Servicing	maintenance-free
Weight	Weight	0.33 kg
	Packaging quantity	Multipack 20 pcs.



# **Technical data sheet**

• This device has been designed for use in stationary heating, ventilation and air-conditioning

	<ul> <li>This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.</li> <li>Outdoor application: only possible in case that no (sea) water, snow, ice, insolation or aggressive gases interfere directly with the device and that it is ensured that the ambient conditions remain within the thresholds according to the data sheet at any time.</li> <li>Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.</li> <li>The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.</li> <li>Cables must not be removed from the device.</li> <li>The rotary supports and coupling pieces are available as accessories and must always be used if transverse forces are likely. An additional installation sheet is required in accordance with the installation instructions. In addition, the actuator must not be tightly bolted to the application. It must remain movable via the rotary support (refer to "Installation notes").</li> <li>If the actuator is not installed horizontally, the magnet-operated gear train disengagement may only be actuated when there is no pressure on the gear rod.</li> <li>To calculate the actuating force required for air dampers and slide valves, the specifications supplied by the damper manufacturers concerning the cross section, the design, the installation situation and the ventilation conditions must be observed.</li> <li>If a rotary support and/or coupling piece is used, actuation force losses are to be expected.</li> <li>The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.</li> </ul>		
<ul> <li>can be replaced or repaired by the user.</li> <li>Cables must not be removed from the device.</li> <li>The rotary supports and coupling pieces are available as accessories and must always be used if transverse forces are likely. An additional installation sheet is required in accordance with the installation instructions. In addition, the actuator must not be tightly bolted to the application. It must remain movable via the rotary support (refer to "Installation notes").</li> <li>If the actuator is exposed to severely contaminated ambient air, appropriate precautions must be taken on the system side. Excessive deposits of dust, soot etc. can prevent the gear rod from being extended and retracted correctly.</li> <li>If the actuator is not installed horizontally, the magnet-operated gear train disengagement may only be actuated when there is no pressure on the gear rod.</li> <li>To calculate the actuating force required for air dampers and slide valves, the specifications supplied by the damper manufacturers concerning the cross section, the design, the installation situation and the ventilation conditions must be observed.</li> <li>If a rotary support and/or coupling piece is used, actuation force losses are to be expected.</li> <li>The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.</li> </ul> Product features Manual override Manual override with magnet possible (gear train disengagement as long as the magnet adheres to the maynet for the gear train disengagement is enclosed. Adjustable stroke If a stroke limitation will be adjusted, the mechanical operating range on this side of the gear			
Simple direct mounting	of the gear rod is connected to the moving part of the ventilating application individually on the		
Manual override	adheres to the magnet symbol). The Z-MA magnet for the gear train disengagement is		
Adjustable stroke	If a stroke limitation will be adjusted, the mechanical operating range on this side of the gear rod can be used starting with an extension length of 20 mm and then can be limited respectively in increments of 20 mm by means of mechanical end stops Z-AS2. If the stroke limiters are used with the motor (with end stop clip Z-ESCM), the operating range can be limited on both sides. It can be adjusted in increments of 0.5 mm (calculatory 0.55 mm) from 040/60/67.5 mm.		
High functional reliability	The actuator is overload protected, requires no limit switches and automatically stops when the end stop is reached.		

#### Accessories

Mechanical accessories	Description	Туре
	End stop kit, Multipack 20 pcs.	Z-AS2
	Rotary support, for linear actuator, for compensation of transverse forces	Z-DS1
	End stop clip, Multipack 20 pcs.	Z-ESCM
	Spring clip, Multipack 20 pcs.	Z-FKCH
	Coupling piece M6	Z-KS2
	Gear train disengagement magnet, Multipack 20 pcs.	Z-MA

#### **Electrical installation**



#### Supply from isolating transformer.


Parallel connection of other actuators possible. Observe the performance data.





#### Wire colours:

- 1 = black
- 2 = red 3 = white


## Wiring diagrams







AC/DC 24 V, 3-point



#### Installation notes



valve).

If a rotary support and/or coupling piece is used, losses in the actuation force losses are to be expected.

The linear actuator is screwed directly to the housing at two points. Afterwards, the head of the gear rod is fastened to the moving part of the ventilation application (e.g. damper or slide

Applications without transverse forces

Applications with transverse forces

Connect the coupling piece with the internal thread (Z-KS2) to the head of the gear rod. Screw the rotary support (Z-DS1) to the ventilation application. Afterwards, the linear actuator is screwed to the previously mounted rotary support with the enclosed screw. Then, the coupling piece, which is mounted to the head of the gear rod, is attached to the moving part of the ventilating application (e.g. damper or slide valve). The transverse forces can be compensated for to a certain limit with the rotary support and/or coupling piece. The maximum permissible swivel angle of the rotary support and coupling piece is 10°, laterally and upwards.

Negative force

If end stop clips (Z-ESCM) are used the following applies: ≤50% of the actuating force (Caution: Use possible only with restrictions. Please contact your supplier.)

If end stops are used on the gear rod or at the application no restrictions apply.

### Dimensions

