Linear actuator for adjusting dampers and slide valves in technical building installations

- Actuating force 150 N
- Nominal voltage AC 100...240 V
- Control Open/close, 3-point
- Length of Stroke Max. 60 mm, adjustable in 20 mm increments



# **Technical data**

	ectrical	-4-4-
-	ectrical	пата

Nominal voltage	AC 100240 V	
Nominal voltage frequency	50/60 Hz	
Nominal voltage range	AC 85265 V	
Power consumption in operation	2 W	
Power consumption in rest position	1 W	
Power consumption for wire sizing	5 VA	
Connection supply / control	Cable 1 m, 3 x 0.75 mm <sup>2</sup>	
Parallel operation	Yes (note the performance data)	

# **Functional data**

Actuating force motor	150 N		
Direction of motion motor	selectable with switch 0 (extended) /		
	1 (retracted)		
Manual override	with push-button, can be locked		
Stroke 60 mm			
Length of Stroke	Max. 60 mm, adjustable in 20 mm increments		
Stroke limitation	can be limited on both sides with mechanical		
	end stops		
Running time motor	150 s / 100 mm		
Running time motor note	corresponds to 90 s / 60 mm		
Sound power level, motor	45 dB(A)		
Destruction of the IEC/EN	W. and Commedition leading		

# Safety data

South power level, filotor	45 db(A)		
Protection class IEC/EN	II, reinforced insulation		
Protection class UL	II, reinforced insulation		
Degree of protection IEC/EN	IP54		
Degree of protection NEMA/UL	NEMA 2		
Enclosure	UL Enclosure Type 2		
EMC	CE according to 2014/30/EU		
Low voltage directive	CE according to 2014/35/EU		
Certification IEC/EN	IEC/EN 60730-1 and IEC/EN 60730-2-14		
UL Approval	cULus according to UL60730-1A, UL60730-2-14 and CAN/CSA E60730-1		
	The UL marking on the actuator depends on		
	the production site, the device is UL-compliant		
	in any case		
Type of action	Type 1		
Rated impulse voltage supply / control	4 kV		
Pollution degree	3		
Ambient humidity	Max. 95% RH, non-condensing		
Ambient temperature	-3050°C [-22122°F]		
Storage temperature	-4080°C [-40176°F]		
Servicing	maintenance-free		

Weight Weight 0.47 kg

#### Safety notes



- This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.
- Outdoor application: only possible in case that no (sea) water, snow, ice, insolation or aggressive gases interfere directly with the device and that it is ensured that the ambient conditions remain within the thresholds according to the data sheet at any time.
- · Caution: Power supply voltage!
- Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- The rotary supports and coupling pieces available as accessories must always be used if transverse forces are likely. In addition, the actuator must not be tightly bolted to the application. It must remain movable via the rotary support (refer to «Installation notes»).
- If the actuator is exposed to severely contaminated ambient air, appropriate precautions must be taken on the system side. Excessive deposits of dust, soot etc. can prevent the gear rod from being extended and retracted correctly.
- If not installed horizontally, the maual override button may only be actuated when there is no pressure on the gear rod.
- To calculate the actuating force required for air dampers and slide valves, the specifications supplied by the damper manufacturers concerning the cross section, the design, the installation situation and the ventilation conditions must be observed.
- If a rotary support and/or coupling piece is used, actuation force losses are to be expected.
- The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.

#### **Product features**

Simple direct mounting

The actuator can be directly connected with the application using the enclosed screws. The head of the gear rod is connected to the moving part of the ventilating application individually on the mounting side or with the Z-KS2 coupling piece provided.

Manual override

Manual override with push-button possible (the gear train is disengaged for as long as the button is pressed or remains locked).

Adjustable stroke

If a stroke limitation will be adjusted, the mechanical operating range on this side of the gear rod can be used starting with an extension length of 20 mm and then can be limited respectively in increments of 20 mm by means of mechanical end stops Z-AS2.

High functional reliability

The actuator is overload protected, requires no limit switches and automatically stops when the end stop is reached.

### Accessories

Mechanical accessories	Description	
	End stop kit, Multipack 20 pcs.	

Rotary support, for linear actuator, for compensation of transverse forces Z-DS1 Coupling piece M6 Z-KS2

#### **Electrical installation**



Caution: Power supply voltage!

Parallel connection of other actuators possible. Observe the performance data.

Type Z-AS2





#### Wire colours:

- 1 = blue
- 2 = brown
- 3 = white

### Wiring diagrams

AC 230 V, open/close





1	2	3	<b>2</b>	
	_~	_/_	<u>\psi}</u>	<b></b>
	~	~	<b>*</b>	₹
	_/_	_/_	stop	stop
	_/_	~	<b>*</b>	¥

### **Installation notes**



If a rotary support and/or coupling piece is used, losses in the actuation force losses are to be expected.

Applications without transverse forces

The linear actuator is screwed directly to the housing at three points. Afterwards, the head of the gear rod is fastened to the moving part of the ventilation application (e.g. damper or slide valve).

Applications with transverse forces

Connect the coupling piece with the internal thread (Z-KS2) to the head of the gear rod. Screw the rotary support (Z-DS1) to the ventilation application. Afterwards, the linear actuator is screwed to the previously mounted rotary support with the enclosed screw. Then, the coupling piece, which is mounted to the head of the gear rod, is attached to the moving part of the ventilating application (e.g. damper or slide valve). The transverse forces can be compensated for to a certain limit with the rotary support and/or coupling piece. The maximum permissible swivel angle of the rotary support and coupling piece is 10°, laterally and upwards.

### **Dimensions**

