


Rotary actuator fail-safe for adjusting dampers in technical building installations

- Air damper size up to approx. 6 m<sup>2</sup>
- Torque motor 30 Nm
- Nominal voltage AC/DC 24 V
- Control Open/close





## **Technical data**

Electrical data	Nominal voltage	AC/DC 24 V	
	Nominal voltage frequency	50/60 Hz	
	Nominal voltage range	AC 19.228.8 V / DC 21.628.8 V	
	Power consumption in operation	9.5 W	
	Power consumption in rest position	4.5 W	
	Power consumption for wire sizing	16 VA	
	Connection supply / control	Cable 1 m, 2 x 0.75 mm² (halogen-free)	
	Parallel operation	Yes (note the performance data)	
Functional data	Torque motor	30 Nm	
	Torque fail-safe	30 Nm	
	Direction of motion motor	selectable by mounting L/R	
	Direction of motion fail-safe	selectable by mounting L/R	
	Manual override	by means of hand crank and locking switch	
	Angle of rotation	Max. 95°	
	Angle of rotation note	adjustable starting at 33% in 5% steps (with mechanical end stop)	
	Running time motor	75 s / 90°	
	Running time fail-safe	<20 s @ -2050°C / <60 s @ -30°C	
	Sound power level, motor	56 dB(A)	
	Sound power level, fail-safe	71 dB(A)	
	Mechanical interface	Universal shaft clamp 1226.7 mm	
	Position indication	Mechanical	
	Service life	Min. 60'000 fail-safe positions	
Safety data	Protection class IEC/EN	III, Safety Extra-Low Voltage (SELV)	
	Degree of protection IEC/EN	IP54	
	EMC	CE according to 2014/30/EU	
	Certification IEC/EN	IEC/EN 60730-1 and IEC/EN 60730-2-14	
	Type of action	Type 1.AA	
	Rated impulse voltage supply / control	0.8 kV	
	Pollution degree	3	
	Ambient humidity	Max. 95% RH, non-condensing	
	Ambient temperature	-3050°C [-22122°F]	
	Storage temperature	-4080°C [-40176°F]	
	Servicing	maintenance-free	
Weight	Weight	4.6 kg	



•

in any other airborne means of transport.

	<ul> <li>aggressive gases interfere directly with the device and that it is ensured that the amolent conditions remain within the thresholds according to the data sheet at any time.</li> <li>Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.</li> <li>The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.</li> <li>Cables must not be removed from the device.</li> <li>To calculate the torque required, the specifications supplied by the damper manufacturers concerning the cross-section, the design, the installation and the ventilation conditions must be observed.</li> <li>The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.</li> </ul>
Product features	
Mode of operation	The actuator moves the damper to the operating position at the same time as tensioning the return spring. The damper is turned back to the safety position by spring energy when the supply voltage is interrupted.
Simple direct mounting	Simple direct mounting on the damper shaft with a universal shaft clamp, supplied with an anti- rotation device to prevent the actuator from rotating.
Shaft stabiliser	The shaft clamp of the spring-return actuator is factory-equipped with a shaft stabiliser for the stabilisation of the combination of damper, damper shaft and actuator.
	This is comprised of two plastic support rings and must be left in place, partially, or completely removed, depending on the installation situation and the shaft diameter.
Manual override	By using the hand crank the damper can be actuated manually and engaged with the locking switch at any position. Unlocking is carried out manually or automatically by applying the operating voltage.
Adjustable angle of rotation	Adjustable angle of rotation with mechanical end stops.
High functional reliability	The actuator is overload protected, requires no limit switches and automatically stops when the end stop is reached.
Accessories	

 This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application, especially in aircraft or

Outdoor application: only possible in case that no (sea) water, snow, ice, insolation or aggressive gases interfere directly with the device and that it is ensured that the ambient

#### **Mechanical accessories** Description Туре IND-EFB End stop indicator Shaft clamp reversible, clamping range Ø12...26.7 mm K9-2 Damper crank arm Slot width 8.2 mm, clamping range Ø14...25 mm KH10 Actuator arm Slot width 8.2 mm KH-EFB Mounting kit for linkage operation for flat and side installation ZG-EFB Anti-rotation mechanism 230 mm, Multipack 20 pcs. Z-ARS230 Hand crank 63 mm ZKN2-B

### **Electrical installation**



Supply from isolating transformer.

Parallel connection of other actuators possible. Observe the performance data.


Wire colours:

1 = black 2 = red



# Wiring diagrams

AC/DC 24 V, open/close  $\overline{\perp}$   $\stackrel{+}{\sim}$ 



# Installation notes



- Shaft stabiliser long shaft mounting


  - 21...26.7 mm is not necessary and can be removed

Shaft stabiliser short shaft mounting

## Dimensions

## Spindle length

	<b>-</b>	Min. 117				
		Min. 2	0			
Clamping range						
	C	<u>)</u>	$\mathbf{r}$			
	1222		1218			
	01		<b>∎</b> I			
	22	26.7	1218			



The shaft stabiliser must nevertheless be used with installation of the anti-rotation device on the opposite side of the shaft clamp and a shaft diameter <20 mm.

In the case of long shaft installation the use of the shaft stabiliser at a shaft diameter of

• 12...20 mm is necessary

**Technical data sheet** 

In the case of short shaft installation, the necessity of the shaft stabiliser is dispensed with. It can be removed or – if the shaft length permits this – left in the shaft clamp.